



INSTRUCTIONS FOR SECURING KEY TRACKER MECHANICAL PEG BOARD SYSTEM

You will need fixing screws and a 3mm Allen key.

- 1/ With the Allen key undo one of the top bolts in the key board and remove.
- 2/ Slide out one or more of the numbered tracks in the board to gain access to the holes in the back of the frame.
- 3/ Screw the frame to the wall ensuring the frame is aligned correctly.
- 4/ Replace the track(s) into the frame.
- 5/ With the Allen key, replace the bolt into the frame and tighten.
- 6/ Repeat with each corner of the frame ensuring the previous fixing bolt is replaced before removing the next one.