

Installation Guidelines

Fatigue Lock

Fatigue Lock Installation Guidelines


Tools & Materials

Tools


- Rubber Mallet
- Safe Utility Knife
- Pencil
- Tape Measure
- Straight Edge

Materials


- Fatigue Lock Tiles
- Fatigue Lock Female Edging
- Fatigue Lock Male Edging
- Fatigue Lock Corner Edge



Fatigue Lock Tile - With Holes



Fatigue Lock Tile - Solid Surface



Preparation

Fatigue Lock Tiles can be laid on damaged or cracked subfloor surfaces. For best results it is advised to install on a level and clean floor. Simply follow these simple steps to achieve a durable, clean and adaptable flooring finish in your chosen area:



Clean

Sweep the existing floor to ensure that the surface is clean and free of dust and dirt.



Temperature

We advise that Fatigue Lock Tiles are laid in areas that have an ambient temperature between 16°C-24°C (**Let the tiles acclimatise for at least 24-48 hours before laying**).



Surface check

We recommend using a self-leveling repair compound in areas where there's variations in subfloor surface. If not addressed, floor tiles may 'dislocate' at the connection interlocks (The smoother the subfloor is the more even and resilient your Fatigue Lock Tile floor will be).





Humidity

Relative humidity in the room should not be more than 60% (ideal 30% to 60%).

Configuration Examples


1



Example 1

- 6 x Fatigue-Lock Tiles
- 7 x Female Edge
- 7 x Male Edge (2 x Cut)
- 5 x Corner Edges

2



Example 2

- 14 x Fatigue Lock Tiles
- 11 x Female Edge (1 x Cut)
- 11 x Male Edge (3 x Cuts)
- 6 x Corner Edges

MORE THAN JUST
MATTING